



Rear Bumper Cover

Application Instructions

Install in a dry clean area. The air temperature must be at least 65 degrees Fahrenheit. Any lubricants, skin oil, airborne dust, will contaminate the adhesive and reduce the bond of the tape.

Clean bumper surface of dirt, oil and contaminants. Use alcohol wipes (included) to clean off all residual debris in application area. Turn wipes and change as they become noticeably dirty.

Make sure bumper and cover are at least 65 degrees Fahrenheit. Warming the cover and bumper will help achieve a faster bond.

Remove tape liner from the tape, being careful not to contaminate the tape with your fingers or hand.

Align arrow on front center of bumper cover with door striker.

Roll cover down onto bumper with 30LBS of force for each 1" of tape area, repeating 5 or 6 times. If no roller is available use rag and press part on by hand making sure all edges and corners are tight.

DO NOT WASH VEHICLE FOR 72 HOURS AFTER APPLICATION.