

C&C CarWorx Corp. 400 Market Ind. Park • #19 Wappingers Falls, NY 12590 • USA 1-888-CAR-WORX (227-9679)

HOW TO INSTALL EXTERIOR SIDE MIRROR RAIN VISOR WEATHER GUARDS ON ANY VEHICLE

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION



QUESTIONS?

Call
1-888-CAR-WORX
(227-9679)



Item #MV-AV-T

BEFORE YOU BEGIN: Thoroughly wash your exterior mirrors. If you believe your vehicle has a paint sealant applied to it, you will need to use a wax and grease remover to thoroughly clean the area where the tape will adhere. The double-sided **3M** tape supplied on the mirror visors adheres and cures best at temperatures above 65 degrees (F). If the deflector is being fitted below 65 degrees, it is advisable to warm the contact area of the mirror as well as the tape supplied on the deflector using a hot air gun or hair dryer. The only materials needed are a couple of clean rags and a bottle of rubbing alcohol.

- 1)** Clean the mirror surface thoroughly to remove any dirt and dust with the supplied alcohol wipes or common rubbing alcohol and let the surface dry completely before installation. Do not touch the surface after cleaning.
- 2)** Peel off the protective tape and stick the visor to the edge of the rear view mirror in the position shown in the above photograph. Do not contaminate the sticky surface of the tape with oil from your fingers or any other substance or your bond will fail.
- 3)** Apply pressure with both hands to the taped area for about a minute in order to facilitate successful adhesion.
- 4)** Allow 72 hrs. for curing of your taped installation before washing. Rain will not affect adhesion after 3 hours.

CLEANING INSTRUCTIONS: After allowing your installation to cure for at least 72 hours, wash with warm water and mild soap solution using a soft, clean cloth or sponge. Avoid using cleaners not approved for acrylic, including improper solvents, which could result in permanent damage and nullify coverage by the 3-year/36,000 mile warranty. These mirror visor rain guard weather deflectors are made of breakage-resistant material, but to avoid damage, machine car washes are not recommended.

The information contained in this document is meant as helpful guidance only and is subject to change without notice. You are welcome to call, write or email us for more information at any time. Thank you for your interest in our products. This document was published 11/25/14.

3M and the 3M logo are worldwide trademarks or registered trademarks of 3M.