

C&C CarWorx Corp. 400 Market Ind. Park • #19 Wappingers Falls, NY 12590 • USA 1-888-CAR-WORX (227-9679)

## GUIDE TO GRILLE INSTALLATIONS

### UPPER CORNER VENTS (TOY-1949) TO FIT 2005-11 TOYOTA TACOMA BASE, PRE RUNNER & X-RUNNER

1



THE VENT GRILLE MUST BE INSTALLED WITH THE LOWER THREADED STUD FACING IN TOWARDS THE CENTER MAIN GRILLE.

2



DRILL HOLES FOR THE THREADED STUDS USING 1/4 INCH DRILL BIT. REMEMBER THE LOWER THREADED STUD HOLE FACES TOWARDS THE MAIN GRILLE CENTER.

3



PLACE GRILLE VENT STUDS INTO DRILLED HOLES.

4



INSTALL SUPPLIED WASHER AND LOCKNUTS. NEXT TIGHTEN LOCK NUT.



**NOTE:**

**THE LOWER THREADED STUD HOLES MUST FACE TOWARDS THE CENTER MAIN GRILLE.**

The information contained in this document is meant as helpful guidance only and is subject to change without notice. You are welcome to call, write or email us for more information at any time. Thank you for your interest in our products. This document was published 06/30/14.

C&C CarWorx Corp. is not in any manner authorized or approved by or connected with Subaru of America, Fuji Heavy Industries, Ltd. or Toyota Motor Corporation and does not sell genuine or authorized Subaru or Toyota original equipment manufacturing (OEM) parts. Toyota, Tacoma, Tundra, X-Runner and Scion FR-S are registered trademarks owned by Toyota Motor Corporation. .