



(SUB-1715) SUBARU IMPREZA MX SERIES HOOD SCOOP GRILLE INSTALLATION DETAILS

(SUB-1715) Subaru Impreza MX Series Hood Scoop Grille

Products : SUB1715B , SUB1715S



Install Step #1:

Here is the GrillCraft custom mesh grille kit for the factory hood scoop. Part# SUB-1715 available in black & silver powder coated finish.



Install Step #2:

Remove the trim cover located under the hood scoop.



Install Step #3:

Remove the bolts that secure the bottom portion of the scoop.



Install Step #4:

Removing the under side portion of the hood scoop.



Install Step #5:

Remove the bolts that secure the hood scoop to the hood.



Install Step #6:

Remove the top of the hood scoop.



Install Step #7:

Using a file notch a small section in the hood scoop center divider as shown. (this notch will let the scoop grille lay flush)



Install Step #8:

Note: The small notch created with the file.



Install Step #9:

Place the grille into the scoop and drill a 3/16 hole for the mounting screw (make sure hole lines up with the mounting tab)



Install Step #10:

The supplied mounting hardware.



Install Step #11:

Now that looks awesome!!!!!!!



Install Step #12:

No more damage to the intercooler!!!!!!!!!!!!!!!