



(SUB-1720) SUBARU IMPREZA MX SERIES LOWER GRILLE INSTALLATION DETAILS



Install Step #1:
Here is the GrillCraft Subaru Impreza / WRX Lower custom mesh grille kit Part# SUB-1720 available in black & silver powder coated finishes



Install Step #2:
Our project Subaru Impreza / WRX STI in need of a custom mesh grille kit.



Install Step #3:
Place the lower grille into bumper opening from the front side.



Install Step #4:
Using a long scribe (a long wire works great) mark mounting tab holes from the front side.



Install Step #5:
Drill 3/16 hole for the mounting screws.



Install Step #6:
Drill 3/16 hole for the mounting screws.



Install Step #7:
The supplied "U" Nuts.



Install Step #8:
Attach the "U" Nuts onto the mounting tabs as shown. Now insert the grille screws from the underside but dont tighten.



Install Step #9:
Remove fog lamp covers.



Install Step #10:
Removing fog lamp cover.



Install Step #11:
Drill a 1/2 access hole in the bumper as shown make sure the hole is in line with the grille screw.



Install Step #12:
Now fasten the grille screws the side screws can be reached through the access hole. The center screw can be accessed from the underside.



Install Step #13:
Our Subaru Impreza Looking good with custom grilles (shown here with optional upper grille)



Install Step #14:
The Subaru Impreza / WRX looks ready for a rally.



Install Step #15:
The GrillCraft Grille fits like a glove with its CNC formed frame.