



(TOY-1964) TOYOTA TUNDRA MX / SW SERIES UPPER GRILLE INSTALLATION DETAILS

(TOY-1964) Toyota Tundra MX / SW Series Upper Grille

Products : TOY1964B , TOY1964S , TOY1964SW



Install Step #1:
Our project Toyota Tundra in need of a custom GrillCraft Grille.



Install Step #2:
Remove the four bolts from the grille extension bracket as shown.



Install Step #3:
Remove the nuts located on the back side of the grille.



Install Step #4:
Remove the hood latch bolts.



Install Step #5:
Remove latch lever from grille as shown.



Install Step #6:
The hood release lever can just hang in place for now.



Install Step #7:
Pry the plastic grille cover using a small flat screwdriver.



Install Step #8:
Remove plastic grille shell trim.



Install Step #9:
Note: Bolts located under the plastic trim.



Install Step #10:
Remove bolts located on the top of the grille shell.



Install Step #11:
Remove grille shell from vehicle.



Install Step #12:
Here is the GrillCraft hood latch extension bracket included with grille kit.

(TOY-1964) TOYOTA TUNDRA MX / SW SERIES UPPER GRILLE INSTALLATION DETAILS



Install Step #13:
 Remove the hood latch bracket from the factory grille.



Install Step #14:
 Removing hood latch bracket screws.



Install Step #15:
 Removing hood latch bracket.



Install Step #16:
 Note: Plastic nubs.



Install Step #17:
 Remove the two plastic nubs using wire cutters.



Install Step #18:
 Place latch extension bracket onto grille as shown.



Install Step #19:
 Fasten latch extension bracket to factory grille as shown.



Install Step #20:
 From the front side of grille scribe the extension bracket holes onto grille shell.



Install Step #21:
 Cut the factory grille center bars off.



Install Step #22:
 Removing factory grille center bars from the grille shell.



Install Step #23:
 Here is the factory grille shell with the center bars removed.



Install Step #24:
 Drill the two scribed holes for the extension bracket.



Install Step #25:
 Mount extension bracket to grille shell.



Install Step #26:
 Fasten extension bracket with supplied hardware.



Install Step #27:
 Mount the factory latch bracket to the extension bracket as shown.



(TOY-1964) TOYOTA TUNDRA MX / SW SERIES UPPER GRILLE INSTALLATION DETAILS



Install Step #28:
Place GrillCraft grille into grille shell opening.



Install Step #29:
Mark grille mounting tab center hole locations using a sharp scribe.



Install Step #30:
Drill 3/16 inch holes for Grille mounting screws.



Install Step #31:
Remove the grille shell metal support along bottom of grille shell.



Install Step #32:
Fasten GrillCraft grille to grille shell using supplied screws.



Install Step #33:
Note: A clearance notch will need to be made to the metal grille support in order to clear the grille screws. Scribe the screw location onto the metal support.



Install Step #34:
Drill 3/8 hole into metal support bracket.



Install Step #35:
A view of the 3/8 hole.



Install Step #36:
Cut the ends to create a notch as shown.



Install Step #37:
Install the metal support to grille shell the cut out notch will now clear grille screws.



Install Step #38:
Fasten support screws.



Install Step #39:
2008 Toyota Tundra shown here with GrillCraft SW Series (Woven Stainless Steel) upper mesh grille kit.



Install Step #40:
2008 Toyota Tundra shown here with GrillCraft SW Series (Woven Stainless Steel) upper mesh grille kit.



Install Step #41:
2008 Toyota Tundra shown here with GrillCraft SW Series (Woven Stainless Steel) upper mesh grille kit.



Install Step #42:
2008 Toyota Tundra shown here with GrillCraft SW Series (Woven Stainless Steel) upper mesh grille kit.



(TOY-1964) TOYOTA TUNDRA MX / SW SERIES UPPER GRILLE INSTALLATION DETAILS



Install Step #43:
2008 Toyota Tundra shown here with GrillCraft SW Series(Woven Stainless Steel) upper mesh grille kit.



Install Step #44:
2008 Toyota Tundra shown here with GrillCraft SW Series(Woven Stainless Steel) upper mesh grille kit.



Install Step #45:
2008 Toyota Tundra shown here with GrillCraft SW Series(Woven Stainless Steel) upper mesh grille kit.



Install Step #46:
2008 Toyota Tundra shown here with GrillCraft SW Series(Woven Stainless Steel) upper mesh grille kit.



Install Step #47:
2008 Toyota Tundra shown here with GrillCraft MX Series(Black)upper mesh grille kit.



Install Step #48:
2008 Toyota Tundra shown here with GrillCraft MX Series(Black)upper mesh grille kit.



Install Step #49:
2008 Toyota Tundra shown here with GrillCraft MX Series(Black)upper mesh grille kit.



Install Step #50:
2008 Toyota Tundra shown here with GrillCraft MX Series(Black)upper mesh grille kit.



Install Step #51:
2008 Toyota Tundra shown here with GrillCraft MX Series(Black)upper mesh grille kit.



Install Step #52:
2008 Toyota Tundra shown here with GrillCraft MX Series(Silver)upper mesh grille kit.



Install Step #53:
2008 Toyota Tundra shown here with GrillCraft MX Series(Silver)upper mesh grille kit.



Install Step #54:
2008 Toyota Tundra shown here with GrillCraft MX Series(Silver)upper mesh grille kit.



Install Step #55:
2008 Toyota Tundra shown here with GrillCraft MX Series(Silver)upper mesh grille kit.