

[SUB-1738] SUBARU IMPREZA MX SERIES HOOD SCOOP GRILLE INSTALLATION DETAILS



Install Step #1:
 Our Project Subaru Impreza Needing a GrillCraft Grille.



Install Step #2:
 Under the hood, you'll need to partially-remove the sound dampener by removing the upper clips holding it in place.



Install Step #3:
 Use a plastic pry-tool or flat blade screw driver to remove the clips.



Install Step #4:
 Underneath the sound dampener, Remove the associated clips and nuts holding the hood scoop to the hood. Pointed to with yellow arrows.



Install Step #5:
 Once all hardware is removed, pinch the center clip in the image to lift the hood scoop away from the hood.



Install Step #6:
 With the Hood Scoop removed from the vehicle, place the mesh insert through the front.



Install Step #7:
 Note the insert sits at a slight angle with the top of the grille behind the top edge of the scoop.



Install Step #8:
 The side tabs sit flush with the edge of the hood scoop, and the center sits about a 3/16" away from the edge.



Install Step #9:
 Using a sharp scribe tool, mark the locations of the mounting tabs.



Install Step #10:
 With the mounting points marked, use a 3/16" drill-bit to drill the necessary mounting holes.



Install Step #11:
 Re-install the mesh insert back into the hood scoop.



Install Step #12:
 Locate the included hardware.



Install Step #13:
 Place the screws through the tabs of the mesh insert.



Install Step #14:
 Install a flat-nut on the opposite end of the screw.



Install Step #15:
 Once all flat nuts are in place, tighten them being sure not to strip the screws.



Install Step #16:
 Reinstall back onto vehicle and installation is complete. Shown here with our Black MX Series Upper & Lower Grille Kits.



Install Step #17:
 Shown here with our Silver MX Series Upper & Lower Grille Kits.