



[SUB-1739] SUBARU IMPREZA MX SERIES UPPER GRILLE INSTALLATION DETAILS



Install Step #1:
Our Project Subaru Impreza Needing a GrillCraft Grille.



Install Step #2:
To perform the install you'll need to remove the bumper from the vehicle. Start by removing the 10mm bolts and Plastic Clips holding the upper part of the bumper.



Install Step #3:
Once the bolts and clips are removed, the metal reinforcement bar comes right off.



Install Step #4:
In the wheel-wells, you'll need to remove the upper clip holding the bumper by pushing the center of the clip inward.



Install Step #5:
Once the center is pushed in, will the clip come out.



Install Step #6:
Underneath the bumper, remove the clips holding the bumper cover to the lower plastics.



Install Step #7:
Once all hardware is removed, you can unclip the bumper from the vehicle by pulling towards you from the wheel-well as well as underneath the bumper.



Install Step #8:
Disconnect the bumper-lights by pushing the center-tab inward.



Install Step #9:
The bumper should be fully detached from the vehicle.



Install Step #10:
You'll need to remove the upper grille shell from the bumper by unscrewing the Phillips screws along the perimeter.



Install Step #11:
Use a flat-blade screwdriver to release the clips holding the grille shell in place.



Install Step #12:
Once all removed, the grille shell will come right out from the front of the bumper.



Install Step #13:
Place your new mesh insert into the bumper opening.



Install Step #14:
Using a sharp scribe tool, mark the locations of the mounting tabs through the grille.



Install Step #15:
Use a 3/16" drill bit to make the necessary mounting holes.



(SUB-1739) SUBARU IMPREZA MX SERIES UPPER GRILLE INSTALLATION DETAILS



Install Step #16:
We recommend painting the area behind the grille BLACK to give a clean, professional installation. To do this trace the back of the grille and tape it off in preparation for painting.



Install Step #17:
Another view of the taped section.



Install Step #18:
Another view of the taped section.



Install Step #19:
Once painted the bumper should look like shown.



Install Step #20:
Another view of the painted section.



Install Step #21:
Another view of the painted section.



Install Step #22:
Locate the included hardware



Install Step #23:
On the bottom tab of the grille, attach the provided U-Clip. Smooth side faces downward.



Install Step #24:
Place the mesh insert back into the bumper opening.



Install Step #25:
The top tab utilizes the 1" Hex Screw and mounts through the upper plastic reinforcement on the bumper.



Install Step #26:
The side tabs attach as shown with the flat-nuts opposite to the hex-screw.



Install Step #27:
The lower screw will attach as shown through the bumper into the previously attached U-Nut.



Install Step #28:
Reinstall the bumper back onto vehicle and installation is complete. Shown here with our Black MX Series Upper, Lower & Hood Scoop Grille Kits.



Install Step #29:
Shown here with our Silver MX Series Upper, Lower & Hood Scoop Grille Kits.