

[SUB-1738] SUBARU IMPREZA MX SERIES HOOD SCOOP GRILLE INSTALLATION DETAILS



Install Step #1:
 Our Project Subaru Impreza Needing a GrillCraft Grille.



Install Step #2:
 Under the hood, you'll need to partially-remove the sound dampener by removing the upper clips holding it in place.



Install Step #3:
 Use a plastic pry-tool or flat blade screw driver to remove the clips.



Install Step #4:
 Underneath the sound dampener, Remove the associated clips and nuts holding the hood scoop to the hood. Pointed to with yellow arrows.



Install Step #5:
 Once all hardware is removed, pinch the center clip in the image to lift the hood scoop away from the hood.



Install Step #6:
 With the Hood Scoop removed from the vehicle, place the mesh insert through the front.



Install Step #7:
 Note the insert sits at a slight angle with the top of the grille behind the top edge of the scoop.



Install Step #8:
 The side tabs sit flush with the edge of the hood scoop, and the center sits about a 3/16" away from the edge.



Install Step #9:
 Using a sharp scribe tool, mark the locations of the mounting tabs.



Install Step #10:
 With the mounting points marked, use a 3/16" drill-bit to drill the necessary mounting holes.



Install Step #11:
 Re-install the mesh insert back into the hood scoop.



Install Step #12:
 Locate the included hardware.



Install Step #13:
 Place the screws through the tabs of the mesh insert.



Install Step #14:
 Install a flat-nut on the opposite end of the screw.



Install Step #15:
 Once all flat nuts are in place, tighten them being sure not to strip the screws.



Install Step #16:
 Reinstall back onto vehicle and installation is complete. Shown here with our Black MX Series Upper & Lower Grille Kits.



Install Step #17:
 Shown here with our Silver MX Series Upper & Lower Grille Kits.

[SUB-1739] SUBARU IMPREZA MX SERIES UPPER GRILLE INSTALLATION DETAILS



Install Step #1:
 Our Project Subaru Impreza Needing a GrillCraft Grille.



Install Step #2:
 To perform the install you'll need to remove the bumper from the vehicle. Start by removing the 10mm bolts and Plastic Clips holding the upper part of the bumper.



Install Step #3:
 Once the bolts and clips are removed, the metal reinforcement bar comes right off.



Install Step #4:
 In the wheel-wells, you'll need to remove the upper clip holding the bumper by pushing the center of the clip inward.



Install Step #5:
 Once the center is pushed in, will the clip come out.



Install Step #6:
 Underneath the bumper, remove the clips holding the bumper cover to the lower plastics.



Install Step #7:
 Once all hardware is removed, you can unclip the bumper from the vehicle by pulling towards you from the wheel-well as well as underneath the bumper.



Install Step #8:
 Disconnect the bumper-lights by pushing the center-tab inward.



Install Step #9:
 The bumper should be fully detached from the vehicle.



Install Step #10:
 You'll need to remove the upper grille shell from the bumper by unscrewing the Phillips screws along the perimeter.



Install Step #11:
 Use a flat-blade screwdriver to release the clips holding the grille shell in place.



Install Step #12:
 Once all removed, the grille shell will come right out from the front of the bumper.



Install Step #13:
 Place your new mesh insert into the bumper opening.



Install Step #14:
 Using a sharp scribe tool, mark the locations of the mounting tabs through the grille.



Install Step #15:
 Use a 3/16" drill bit to make the necessary mounting holes.

[SUB-1739] SUBARU IMPREZA MX SERIES UPPER GRILLE INSTALLATION DETAILS



Install Step #16:

We recommend painting the area behind the grille BLACK to give a clean, professional installation. To do this trace the back of the grille and tape it off in preparation for painting.



Install Step #17:

Another view of the taped section.



Install Step #18:

Another view of the taped section.



Install Step #19:

Once painted the bumper should look like shown.



Install Step #20:

Another view of the painted section.



Install Step #21:

Another view of the painted section.



Install Step #22:

Locate the included hardware



Install Step #23:

On the bottom tab of the grille, attach the provided U-Clip. Smooth side faces downward.



Install Step #24:

Place the mesh insert back into the bumper opening.



Install Step #25:

The top tab utilizes the 1" Hex Screw and mounts through the upper plastic reinforcement on the bumper.



Install Step #26:

The side tabs attach as shown with the flat-nuts opposite to the hex-screw.



Install Step #27:

The lower screw will attach as shown through the bumper into the previously attached U-Nut.



Install Step #28:

Reinstall the bumper back onto vehicle and installation is complete. Shown here with our Black MX Series Upper, Lower & Hood Scoop Grille Kits.



Install Step #29:

Shown here with our Silver MX Series Upper, Lower & Hood Scoop Grille Kits.



[SUB-1740] SUBARU IMPREZA MX SERIES LOWER GRILLE INSTALLATION DETAILS



Install Step #1:
Our Project Subaru Impreza Needing a GrillCraft Grille.



Install Step #2:
To perform the install you'll need to remove the bumper from the vehicle. Start by removing the 10mm bolts and Plastic Clips holding the upper part of the bumper.



Install Step #3:
Once the bolts and clips are removed, the metal reinforcement bar comes right off.



Install Step #4:
In the wheel-wells, you'll need to remove the upper clip holding the bumper by pushing the center of the clip inward.



Install Step #5:
Underneath the bumper, remove the clips holding the bumper cover to the lower plastics.



Install Step #6:
Once all hardware is removed, you can unclip the bumper from the vehicle by pulling towards you from the wheel-well as well as underneath the bumper.



Install Step #7:
Disconnect the bumper-lights by pushing the center-tab inward.



Install Step #8:
The bumper should be fully detached from the vehicle.



Install Step #9:
Place the new mesh insert into the lower bumper opening.



Install Step #10:
Using a sharp scribe tool, mark the locations of the mounting tabs.



Install Step #11:
Use a 3/16" Drill Bit to drill the holes at the mounting locations.



Install Step #12:
Use a 3/16" Drill Bit to drill the holes at the mounting locations.



Install Step #13:
Now remove the factory lower plastic insert by releasing the tabs along its perimeter.



Install Step #14:
Once all tabs are released, the insert comes right off.



Install Step #15:
Locate the included hardware.



(SUB-1740) SUBARU IMPREZA MX SERIES LOWER GRILLE INSTALLATION DETAILS



Install Step #16:
With the mesh insert back in place, use the included hardware to mount the insert in place.



Install Step #17:
With the mesh insert back in place, use the included hardware to mount the insert to the bumper.



Install Step #18:
The top tab is notched when drilled; this is to secure the mesh to the bumper without risk of tearing the plastic tab.



Install Step #19:
The hardware will clamp the mesh insert to the bumper, making it impossible to remove without unscrewing.



Install Step #20:
Reinstall the bumper back onto vehicle and installation is complete. Shown here with our Black MX Series Upper, Lower & Hood Scoop Grille Kits.



Install Step #21:
Shown here with our Silver MX Series Upper, Lower & Hood Scoop Grille Kits.