



# (TOY-1960) TOYOTA TUNDRA MX SERIES UPPER GRILLE

## INSTALLATION DETAILS



**Install Step #1:**  
GrillCraft Toyota Tundra Upper MX-Series Upper Grille Kit Part# TOY-1960 Available in silver or black powder coat finishes.



**Install Step #2:**  
Here is our project Tundra in need of a GrillCraft Sport Grille make over.



**Install Step #3:**  
Remove the hood safety release.



**Install Step #4:**  
Remove the upper grille nuts from the backside as shown.



**Install Step #5:**  
Here is the grille removed from the vehicle.



**Install Step #6:**  
The center section will need to be cut out. (Make sure not to cut the area of the safety latch or where the new grille insert screws will be located)



**Install Step #7:**  
Note: Safety latch area must stay do not cut this off.



**Install Step #8:**  
Note: Do not cut this area this will be needed when mounting the new grille insert screws.



**Install Step #9:**  
The stock grille shell with the center cut out.



**Install Step #10:**  
The new Sport Grille Kit.



**Install Step #11:**  
Place the sport grille into grille shell from the front side and mark right & left mounting tab holes.



**Install Step #12:**  
Using 3/16 drill bit drill holes for the right & left mounting screws.



# (TOY-1960) TOYOTA TUNDRA MX SERIES UPPER GRILLE

## INSTALLATION DETAILS



**Install Step #13:**  
Fasten the right & left mounting screws as shown.



**Install Step #14:**  
Now mark upper & lower mounting tabs. (this process will insure a proper fit)



**Install Step #15:**  
With the Sport Grille removed drill for the remaining mounting screws and fasten all screws.



**Install Step #16:**  
Toyota Tundra with custom grille installed.



**Install Step #17:**  
Toyota Tundra with custom grille installed.



**Install Step #18:**  
Toyota Tundra with custom grille installed.



**Install Step #19:**  
Toyota Tundra with custom grille installed.